

One touch fittings

PCF

Female Straight



Model (øD-T)		
Tube(Metric)-Thread(R)		
PCF04-M5	PCF06-04	PCF10-04
PCF04-01	PCF08-01	PCF12-02
PCF04-02	PCF08-02	PCF12-03
PCF04-03	PCF08-03	PCF12-04
PCF06-M5	PCF08-04	
PCF06-01	PCF10-01	
PCF06-02	PCF10-02	
PCF06-03	PCF10-03	

PLF

Female Elbow



Model (øD-T)		
Tube(Metric)-Thread(R)		
PLF04-M5	PLF06-03	PLF10-03
PLF04-M6	PLF06-04	PLF10-04
PLF04-01	PLF08-01	PLF12-02
PLF04-02	PLF08-02	PLF12-03
PLF06-M5	PLF08-03	PLF12-04
PLF06-M6	PLF08-04	
PLF06-01	PLF10-01	
PLF06-02	PLF10-02	

PMF

Bulkhead Female Straight



Model (øD-T)	
Tube(Metric)-Thread(R)	
PMF04-01	PMF08-04
PMF04-02	PMF10-01
PMF04-03	PMF10-02
PMF06-01	PMF10-03
PMF06-02	PMF10-04
PMF06-03	PMF12-02
PMF08-01	PMF12-03
PMF08-02	PMF12-04
PMF08-03	

PT

Male Branch Tee



Model (øD-T)		
Tube(Metric)-Thread(R)		
PT04-M5	PT06-03	PT10-04
PT04-M6	PT06-04	PT12-01
PT04-01	PT08-01	PT12-02
PT04-02	PT08-02	PT12-03
PT04-03	PT08-03	PT12-04
PT06-M5	PT08-04	PT16-03
PT06-M6	PT10-01	PT16-04
PT06-01	PT10-02	
PT06-02	PT10-03	

PST

Male Run Tee



Model (øD-T)		
Tube(Metric)-Thread(R)		
PST04-M5	PST06-02	PST10-02
PST04-M6	PST06-03	PST10-03
PST04-01	PST06-04	PST10-04
PST04-02	PST08-01	PST12-01
PST04-03	PST08-02	PST12-02
PST06-M5	PST08-03	PST12-03
PST06-M6	PST08-04	PST12-04
PST06-01	PST10-01	

PWT

Male Y



Model (øD-T)		
Tube(Metric)-Thread(R)		
PWT04-M5	PWT06-02	PWT10-02
PWT04-M6	PWT06-03	PWT10-03
PWT04-01	PWT06-04	PWT10-04
PWT04-02	PWT08-01	PWT12-01
PWT04-03	PWT08-02	PWT12-02
PWT06-M5	PWT08-03	PWT12-03
PWT06-M6	PWT08-04	PWT12-04
PWT06-01	PWT10-01	

PH

Male Banjo



Model (øD-T)	
Tube(Metric)-Thread(R)	
PH04-M5	PH08-02
PH04-M6	PH08-03
PH04-01	PH08-04
PH04-02	PH10-01
PH06-M5	PH10-02
PH06-M6	PH10-03
PH06-01	PH10-04
PH06-02	PH12-02
PH06-03	PH12-03
PH06-04	PH12-04
PH08-01	

PHF

Female Banjo



Model (øD-T)	
Tube(Metric)-Thread(R)	
PHF04-M5	PHF08-02
PHF04-M6	PHF08-03
PHF04-01	PHF08-04
PHF04-02	PHF10-01
PHF06-M5	PHF10-02
PHF06-M6	PHF10-03
PHF06-01	PHF10-04
PHF06-02	PHF12-02
PHF06-03	PHF12-03
PHF06-04	PHF12-04
PHF08-01	